



VERLEGEANLEITUNG

I. Wichtige Hinweise

Vor der Verlegung sollten Sie folgende, wichtige Hinweise beachten:

- Holz ist ein hygroskopischer natürlicher Baustoff, der seine Feuchtigkeit an die Umgebung angleicht. Damit versteht man das „Arbeiten des Holzes“: Quellen und Schwinden.
- marinaflexx wird mit einer Materialfeuchte von 40% RLF (relative Luftfeuchtigkeit), +/-10% ausgeliefert. Damit wird die Funktionalität bei einem Raumklima von 30% - 60% RLF bei 18°-26°C sichergestellt.
- Durch den vorgeschriebenen Einbau der FIDBOX wird die Kontrolle des gesunden Wohnraumklimas erleichtert.
- Die Klimawerte können bequem per FIDBOX APP automatisch abgerufen werden.
- Aufgrund der Materialstärke von marinaflexx (10mm) muss die FIDBOX in den Estrich eingebaut werden.

II. Verlegevorbereitung

- Der Untergrund ist nach den einschlägigen Normen gemäß Belegreife für Parkettarbeiten zu prüfen.
- Der Untergrund muss je nach Beschaffenheit entsprechend den Vorschriften des Klebstoffherstellers vorbehandelt werden. (Voranstriche, Spachtelungen, Entkoppelungen, Feuchtigkeitssperren, Feuchtigkeitsabdichtungen)
- Die Untergrundebenheit ist mit einer 100cm langen Messlatte zu prüfen; die Abweichung darf höchstens 2 mm im Stichmaß betragen.
- Verlegetemperaturen des Untergrundes müssen mindestens 15°C und dürfen höchstens 25°C betragen. Die Luftfeuchtigkeit darf kurzfristig höchstens 70% RLF betragen.
- Verlegen Sie immer aus mehreren Paketen gleichzeitig für ein harmonisches Farb- und Sortierbild.

III. Vollflächige Verklebung

- Sonnberg marinaflexx ist vollflächig zu verkleben und zusätzlich mit wasserfestem Leim allseitig in Nut & Feder zu verleimen. Nur durch diese Verlegevorschrift kann ein fugenfreier Holzboden entstehen.
- Auftragen des wasserfesten Leimes in die Nuten des Elementes. Ausgetretener Leim muss sofort mit einem feuchten, sauberen Tuch entfernt werden.
- Die erste Dielenreihe wird zur Wand gerade ausgerichtet. **ACHTUNG: Nutseite zur Wand!** Verwenden Sie eine Richtschnur!
- Tragen Sie den vorgeschriebenen Klebstoff, z.B. 2-Komponenten PU-Parkettklebstoff, laut Herstellerangaben auf. **ACHTUNG: Nur weichmacherfreie Kleber verwenden – siehe Aufbauempfehlung!** Den Klebstoff mit einer Zahnpastel nur für die gleich zu belegende Fläche auftragen. **ACHTUNG: Offene Zeit des Klebers!**
- Legen Sie das Parkett in das Klebstoffbett ein. Nut & Feder vorsichtig zusammenschieben bis keine Fuge zwischen den Elementen mehr sichtbar ist. **ACHTUNG: Nicht zu fest zueinander pressen, um eine Deformierung der Gummifuge zu verhindern!** Um eine gute Klebstoffbenetzung zu erreichen, kann ein Andrücken und Beschweren nötig sein. Bitte beachten Sie, dass kein Parkettklebstoff zwischen den Verlegeelementen austritt und an die Oberfläche gelangt.

IV. Reinigung & Pflege

- Nach der Verlegung des Parkettbodens ist eine Erstpflge mit der PJ Ölpflege unverdünnt durchzuführen.
- Für die Reinigung und Pflege der Oberfläche wird die PJ Ölpflege vorgeschrieben und ist laut des Produktdatenblattes anzuwenden.
- Hinweis: Andere Pflegeprodukte können die Oberfläche des Parkettbodens beschädigen!
- Pflegeanleitung und vorgeschriebene Pflegeprodukte erhalten Sie unter: <https://www.parkettboden.at/shop>
- Anleitungen, Datenblätter, sowie Pflege- und Reinigungsvorschriften finden Sie unter <https://www.marinaflexx.at/downloads>



INSTALLATION INSTRUCTIONS

I. Important notes

Before installation, be aware of the following important notes:

- Wood is a hygroscopic natural building material that adjusts its humidity to the environment. As a result one understands the "work of wood": swelling and shrinkage of wood.
- marinaflexx is delivered with a material humidity of 40% RH (relative humidity), +/-10%. This ensures functionality in a room climate of 30% - 60% RH at 18°-26°C.
- The mandatory installation of the FIDBOX facilitates the control of a healthy indoor environment.
- The climate values can be conveniently retrieved automatically via FIDBOX APP.
- Due to the material thickness of marinaflexx (10mm), the FIDBOX must be installed in the floor screed.

II. Preparation before installation

- The substrate must be tested according to the relevant standards in accordance with readiness for covering parquet work.
- Depending on its condition, the substrate must be pre-treated in accordance with the adhesive manufacturer's instructions. (Primers, levelling, decoupling, moisture barriers, damp proofing)
- The evenness of the substrate must be checked with a 100 cm measuring rod; the deviation must not exceed 2 mm in the gauge.
- The temperature of the substrate must be at least 15°C and not more than 25°C. The air humidity must not exceed 70% RH for a short period of time.
- To achieve a harmonious color and grading appearance always lay from different packages at the same time.

III. Full-surface bonding

- Sonnberg marinaflexx is to be glued over the entire surface and additionally glued in tongue & groove on all sides with waterproof glue. A joint-free wooden floor can only be created by following these installation instructions.
- Apply the waterproof glue into the grooves of the element. Leaked glue must be removed immediately with a damp, clean cloth.
- The first row of planks has to be aligned straight to the wall. **ATTENTION: Groove side to the wall!** Use a cord or string line!
- Apply the specified adhesive, e.g., 2-component PU parquet adhesive, according to the manufacturer's instructions. **ATTENTION: Only use plasticizer-free adhesives – see setup recommendation!** Apply the adhesive with a toothed spatula only for the area to be covered in the same way. **ATTENTION: Open time of the adhesive!**
- Lay the parquet into the adhesive bed. Carefully push the tongue & groove together until no joint is visible between the elements. **ATTENTION: Do not press too tightly together to prevent deformation of the rubber joint!** Pressing and weighting may be necessary to achieve good adhesive wetting. Please ensure that no parquet adhesive escapes between the joints and reaches the surface.

IV. Cleaning & maintenance

- After the installation of the parquet floor, perform initial care with PJ Oil Care undiluted.
- PJ Oil Care is prescribed for cleaning and maintenance of the surface and is to be applied according to the product data sheet.
- Note: Other care products can damage the surface of the parquet floor!
- Care instructions and required care products are available on: <https://www.parkettboden.at/shop>
- Instructions, data sheets, as well as cleaning and maintenance instructions can be found at <https://www.marinaflexx.at/downloads>